

1. Lay panel flat, front side facing up.



2. Fold entire group of flaps at lower left corner into a vertical position. Then fold left and right tabs upward as shown in illustration.



3. Continue folding left and right flaps upward and toward each other as shown in illustration.



4. Turn main panel so that it is positioned in a vertical plane and fold the large flap on the upper right toward the front as shown. Continue folding left and right flaps toward each other until they are parallel and fold narrow vertical panel backwards as shown.



5. Push "box" assembly down so that its slots are aligned with those in the main panel just below.



6. Continue to press "box" down until the slots engage and fully seat with the bottom of the box in line with the main panel as shown below.



7. Finished assembly should look as shown in the illustration below.

